


NOTES:

- 1 AN APPROVED BACKFLOW PREVENTION ASSEMBLY SHALL BE INSTALLED BETWEEN THE EXISTING AND NEW WATER LINES DURING DISINFECTION AND FLUSHING OF NEW WATERMAIN.
- 2 THE BACKFLOW PREVENTION ASSEMBLY AND SUPPLY HOSE MUST BE DISCONNECTED DURING HYDROSTATIC PRESSURE TESTING OF THE NEW MAIN.
- 3 THE NEW WATERMAIN SHALL BE CONNECTED TO THE EXISTING SYSTEM ONLY AFTER NEW MAIN IS FLUSHED, DISINFECTED AND SATISFACTORY BACTERIOLOGICAL SAMPLE RESULTS ARE OBTAINED.
- 4 THE INTERIORS OF ALL PIPES AND FITTINGS TO BE USED IN FINAL CONNECTION MUST BE SWABBED OR SPRAYED WITH A 1% AVAILABLE CHLORINE SOLUTION.
- 5 2" HYDRANT METER SHALL BE OBTAINED FROM THE CITY OF KIRKLAND PUBLIC WORKS DEPARTMENT.
- 6 DISCHARGE FLUSHING TO SEWER ONLY. PROVIDE AIR GAP AT DISCHARGE.

CITY OF KIRKLAND	
PLAN NO. CK-W.10	
	FILLING NEW WATER MAINS